

Mount for Cannondale Knot / Save Systems

Pack Contents:

- 1x JRC Components Mount for Hollowgram Stems
- 2x Longer 22mm retention bolt

1. Pre-Installation Check:

- Ensure that you have the required tools before you begin: hex keys, a certified torque wrench and **Loctite 242 (blue)** - this is recommended by Cannondale for installation of the mounting bolts into the stem threads.
- Remove the existing 18mm retention bolts and the specific **Cannondale washer plate** from your Cannondale Hollowgram stem. Retain the 18mm bolts as spares, if you should wish to remove the mount in future.

2. JRC Knot/Save Mount Installation:

- Carefully place the **Cannondale washer plate** between the mount and the underside of the stem. This washer plate is crucial for proper mounting, stability and to avoid the mount from loosening.
- Insert both of the longer 22mm bolts through the mount and plate, applying the Loctite 242 adhesive on the bolts before threading them into the designated threaded holes in your stem.
- Set the mount to your desired angle by releasing the two center bolts. Hold the mount in position while you retighten these bolts firmly, up to a maximum of 2Nm.

3. Bolt tightening:

- Tighten the 2 mounting bolts *evenly* to Cannondale's recommended torque. Refer to the most recent guidance for your stem.
- The *correct* use of a certified torque wrench is recommended for precise installation.

4. Pre-Ride Check:

- After torquing the bolts appropriately, apply some vertical and lateral force to the handlebars by pushing/pulling on them, sufficient to ensure they are secure and without play so that the bike is safe to ride.

Troubleshooting:

- If the mount is rattling during the pre-ride check, stop and recheck the installation of both mount and device to ascertain the cause.
- Do not keep tightening the bolts without checking if there is an issue with the fit of the GPS device to the mount insert.
- Test ride again.

Important Note:

- It is important to follow these steps *meticulously* to guarantee the proper installation and secure usage of the Cannondale Knot / Save Stem Mount.
- If you encounter any difficulties during installation, or if you're unsure about any step, it is recommended to seek assistance from a suitably certified bicycle mechanic.
- Please note that a **MAXIMUM WEIGHT LIMIT of 350 grams** applies to the Knot/Save mount. Please be aware of this when using a combination of a GPS computer and any extra devices such as lights and cameras.



